



Operation Manual

Horizontal Core Bun Toaster CBT-SB-NA-1PS

Product Identification



LIMITED WARRANTY

This product is warranted to be free from defects in material and/or workmanship for a period of two (2) years from date of original installation, not to exceed 30 months from date of shipment from our factory. Any part or component which proves to be faulty in material and/or workmanship within the warranty period will be replaced or repaired (at the option of Prince Castle, Inc.) without cost to the customer for parts or labor.

This warranty is subject to the following exceptions/conditions:

- Use of any non-genuine Prince Castle parts voids this warranty and all work must be performed by an authorized Prince Castle Service Agent.
- All labor shall be performed during regular work hours. Overtime premium will not be covered.
- Travel charges are limited to 200 kilometers (100 miles) round trip, 2 hours travel time, one trip per repair.
- Damage caused by carelessness, neglect, and/or abuse (e.g., using wrong current, dropping, tampering with or altering electrical components, or improper cleaning) is not covered.
- Equipment damaged in shipment, by fire, flood or an act of God is not covered.
- Damage to non-stick coated surfaces is not covered by this warranty.

TABLE OF CONTENTS

Product Identification.....	Page 1
Warranty Statement.....	Page 1
Table of Contents.....	Page 1
Electrical Specifications.....	Page 2
Safe Service Practices.....	Page 2
Serial Number Matrix.....	Page 2
Installation.....	Page 5
Operation.....	Page 6
Cleaning.....	Page 7
Silicone Belt Cleaning.....	Page 11
Silicone Belt Install.....	Page 12
Bun Deflector Bar Install.....	Page 13
Silicone Wrap Removal.....	Page 14
Release Sheet Replacement.....	Page 15
Club Belt Replacement.....	Page 16
Display Menu Options.....	Page 18
Management Programming.....	Page 20
Exploded View and Parts List.....	Page 23
Troubleshooting Guide.....	Page 31



355 East Kehoe Blvd. • Carol Stream, IL 60188 USA
Telephone: 630-462-8800 • Toll Free: 1-800-PCASTLE
Fax: 630-462-1460 • www.princecastle.com

Horizontal Core Bun Toaster

CBT-SB-NA-1PS



Electrical Specifications


CBT-SB-NA-1PS 200-240VAC, 50/60 Hz, 1 Ph.

Disconnect Power



WARNING

Failure to turn off the unit before servicing could result in severe bodily injury or death. Switch the On/Off switch to the Off position



Important

Prince Castle reserves the right to change specifications and product design without notice. Such revisions do not entitle the buyer to corresponding changes, improvements, additions, or replacements for previously purchased equipment.

Safe Service Practices



WARNING

Indicates information important to the proper operation of the unit. Failure to observe may result in damage to the equipment and/or severe bodily injury or death.



CAUTION

Indicates information important to the operation of the unit. Failure to observe may result in damage to the equipment.

GENERAL

This appliance is designed for toasting bread products in a commercial McDonalds kitchen. The dimensions of the bread products as defined by McDonalds.



CAUTION

Do not hose down or use a water jet on the unit. Keep the unit away from running water. Disconnect power cord before performing any cleaning or maintenance.



CAUTION

Equipment must be elevated from the floor at all times during cleaning and operation.

Serial Number Matrix

The manufacture date is encoded in the unit's serial number. The service bench installation date (used to determine warranty coverage) is considered to be the end of the following month. For example:

Serial Number: FJ0000458
Manufacture Date: June 2014
Service Bench Installation Date: July 31, 2014

		SERIAL NUMBER MATRIX									
		2014	2015	2016	2017	2018	2019	2020	2021	2022	
		J	K	L	M	N	O	P	Q	R	
January	A	AJ	AK	AL	AM	AN	AO	AP	AQ	AR	
February	B	BJ	BK	BL	BM	BN	BO	BP	BQ	BR	
March	C	CJ	CK	CL	CM	CN	CO	CP	CQ	CR	
April	D	DJ	DK	DL	DM	DN	DO	DP	DQ	DR	
May	E	EJ	EK	EL	EM	EN	EO	EP	EQ	ER	
June	F	FJ	FK	FL	FM	FN	FO	FP	FQ	FR	
July	G	GJ	GK	GL	GM	GN	GO	GP	GQ	GR	
August	H	HJ	HK	HL	HM	HN	HO	HP	HQ	HR	
September	J	JJ	JK	JL	JM	JN	JO	JP	JQ	JR	
October	K	KJ	KK	KL	KM	KN	KO	KP	KQ	KR	
November	L	LJ	LK	LL	LM	LN	LO	LP	LQ	LR	
December	M	MJ	MK	ML	MM	MN	MO	MP	MQ	MR	


Installation

- 1 Unpack and Inspect.** Remove the unit from the carton and inspect for signs of damage. If there is damage to the unit:

- Notify the carrier within 24 hours of delivery
- Save carton and packaging materials for inspection purposes.
- Contact your local dealer.

- 2 Verify parts.** Verify that all parts have been received. When replacing parts use Prince Castle parts only.

- Horizontal Core Bun Toaster
- In-Feed Rack
- Landing Zone
- Release Sheet Clips



- Release Sheet Mounting Bars (2X)



- Release Sheets (2X)



- 3 Place toaster on flat surface.** Remove blue and/or white protective covering.



CAUTION


Two man lift, unit weight is more than 150 lbs.

- 4 Follow daily PM procedures.** (for first time use)

- 5 Connect heated landing zone.** Slide the **heated landing zone** into the connector verifying the pins are in the correct orientation. The connector can only be inserted one way. Once the connector is fully inserted, secure by turning clockwise.



Install heated landing zone . Slide the landing zone onto 1 hook on each side. Ensure the landing zone is secure before operating the unit.



Install In-Feed Rack. Insert the infeed rack onto the two notches on the front side of the unit

Horizontal Core Bun Toaster


CBT-SB-NA-1PS



Installation


6

Feed release sheets through the toaster, in-feed to out-feed and connect the release sheet mounting bars.




9

Visually inspect that the sheets are taught and ripple free over the heater platen afterwards by peering down the heating chamber. Disconnect clips and reset if not.



7

Clip the heel-side release sheet first being sure to shift the sheet toward the upper step corner on the platen as shown.



8

Connect retaining clips by holding the release sheet tight over the mounting rods, ensuring that they are straight. Press clips over rods until there is solid engagement.



10

Plug unit in. Plug unit into a grounded receptacle with a matching plug configuration.



WARNING

All electrical connections must be in accordance with local electrical codes and any other applicable codes.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid hazards.

To prevent an electric shock hazard, this device must be bonded to equipment in close proximity with an equipotential bonding conductor. This device is equipped with grounding lug for this purpose and is marked with the following symbol.



Horizontal Core Bun Toaster


CBT-SB-NA-1PS



Operation

1

Turn unit ON. Turn the On/Off switch located on back of toaster to ON. The Prince Castle screen will appear in the display for three seconds. (Ensure the conveyor is fully closed)



2

Wait through Warm-Up. During Warm-Up, the LCD display will read "WARMING UP". Warm-Up time, is about 20 minutes.

3



WARNING


BURN/ELECTRICAL SHOCK HAZARD! Platen sections are HOT and can cause severe burns or severe shock. Keep hands and objects out of the toaster unit! Failure to exercise caution may result in serious injury! Turn the unit off, and let it cool down completely before touching or working on internal apparatus.

Watch for READY status. When ready temperature is reached, the LCD display will read "READY".



4

View temperatures, if desired. Pressing the TEMPERATURE button once will display the front and rear platen actual temperatures. Pressing a second time will return the LCD display to the READY screen.



4

Choose the compression adjustments. Dial the platen adjustment for the product part (Crown and Heel). The default settings are set to a compression of 3. To adjust compression, press in on the metal plate, and move compression adjustment lever to the desired position.


Because of variances in bun production, it may be necessary to adjust the bun compression for the Crown and Heel. The Club compression is not adjustable. Increase bun compression if buns are toasted too light. Be careful not to over compress the buns.



5

Feeding in Buns. Feed buns cut side up in the appropriate lanes of the in-feed rack. Facing the in-feed rack from left to right, the proper order is:

Lane 1	Lane 2	Lane 3	Lane 4	Lane 5
CROWN	CROWN	HEEL	HEEL	CLUB



6

Adjusting Toast. For lighter toast, press and hold, ~5 seconds, directional key (left) until indicator move towards lighter rectangle. For darker toast, repeat with the direction key (right) that points toward the blackened rectangle.



Operation

7

Remove Stuck Product. Retrieve stuck product by first shutting off the power to the unit. Depressing latch on left side of in-feed conveyor assembly and gently open enough to retrieve the stuck product. **BE CAREFUL NOT TO CONTACT HEATER PLATEN DURING RETRIEVAL, IT WILL BE VERY HOT.** Gently close the conveyor assembly until latch is closed when retrieval is complete.



Horizontal Core Bun Toaster

CBT-SB-NA-1PS



Cleaning—Daily

1

Remove crumbs from the crumb collection portal by wiping with a clean, sanitizer-soaked towel. Then, clean the crumb collection portal with a clean, sanitizer-soaked towel sprayed with Heavy Duty Degreaser solution. Rinse with a separate, clean, sanitizer-soaked towel.



4

Wipe out landing zone tray with a clean, sanitizer-soaked towel sprayed with Heavy Duty Degreaser solution. Rinse with a separate, clean sanitizer-soaked towel.




2

Wipe out crumbs from conveyor crumb collection shelf below the conveyor tray with sanitizer-soaked towel. Gently, unlatch and pull forward the conveyor assembly and further wipe away. Then wipe the conveyor crumb collection shelf with a clean, sanitizer-soaked towel sprayed with Heavy Duty Degreaser solution. Rinse with a separate clean sanitizer-soaked towel.



5

Remove Teflon release sheet retaining clips located over landing zone by lifting straight up. Be careful not to lose the retaining clips. Clean with a with a clean, sanitizer-soaked towel sprayed with Heavy Duty Degreaser solution. Rinse with a separate clean, sanitizer-soaked towel.



3

Wipe down in-feed rack with a clean, sanitizer-soaked towel sprayed with Heavy Duty Degreaser solution. Rinse with a separate clean, sanitizer-soaked towel.



6

Remove Teflon release sheets by first removing the in-feed rack and the by lifting up gently on the front retaining brackets located over the in-feed. Be careful not to lose the retaining brackets. Lay release sheets on a clean surface before cleaning.



Cleaning—Daily

7

Being careful not to crease the sheet, wipe release sheets with a clean, sanitizer-soaked towel sprayed with APSC solution. Rinse with a separate clean, sanitizer-soaked towel. Wash, rinse, and sanitize the retaining clips at the 3-compartment sink. Allow to air dry.



10

Reconnect retaining clips by holding the release sheet tight over the mounting rods, ensuring that they are straight. Press clips over rods until there is solid engagement.




8

Re-feed the clean release sheets back through the toaster, in-feed to out-feed and reconnect the brackets.



11

Visually inspect that the sheets are taught and ripple free over the heater platen afterwards by peering down the heating chamber. Disconnect clips and reset if not.



9

Re-clip heel-side release sheet first being sure to shift the sheet toward the upper step corner on the platen as shown.




Cleaning—Daily

- 12** Remove in-feed rack and the depress latch on left hand side of in-feed and gently pull out conveyor until it stops. Clean conveyor belt with Kay Heavy duty Degreaser as follows:

1. Spray conveyor belt with heavy duty degreaser solution
2. Wipe belt from side to side, parallel with belt grain, removing brown residue
3. Rinse the same area with a clean, sanitizer-soaked towel to clear particulate.
4. Manually advance the conveyor belt to clean the next section.

Repeat steps 1-4 until entire conveyor belt has been cleaned.



- 13** Wipe down entire unit with a clean, sanitizer-soaked towel sprayed with Heavy Duty Degreaser solution. Rinse with a clean, sanitizer-soaked towel.



Horizontal Core Bun Toaster

CBT-SB-NA-1PS



Cleaning—Weekly / As Needed

- 1** Put on Heat Resistant Gloves. Open the conveyor drawer. Ensure toaster is hot before applying Heat Activated Grill & Toaster Cleaner (HAGTC). Apply a small amount HAGTC to a clean, sanitizer-soaked grill cloth and then spread evenly across exposed section of belt to completely coat the belts. Repeat applying product until all areas of the belt are coated. Close conveyor and let run for 5 seconds to advance the belt to new location before applying additional cleaner.




- 2** Spread solution onto belt, going across/with the grain of the belt.




- 3** Close the conveyor assembly, and allow conveyor to run for 6 minutes. (Stains will begin to darken)



- 4** Wipe stains with a clean, sanitizer-soaked grill cloth, wiping straight across the belts until soils are removed. Open/close conveyor until entire belt has been cleaned.



- 5** Rinse entire belt with a separate, clean sanitizer-soaked grill cloth thoroughly.



- 6** Close the conveyor drawer by sliding in, until locked in place.



Silicone Belt Cleaning—Daily, Weekly & Monthly / As Needed

Silicone Belt Cleaning

Daily

Wipe down entire belt with clean, sanitizer-soaked towel to remove breakfast crumbs.

Twice weekly

Put on heat-resistant gloves. Spray KAY Heat Activated Grill & Toaster Cleaner HAGTC onto a clean, sanitizer-soaked grill cloth and wipe the hot silicone belt. Do not spray cleaner directly onto belt. Repeat until entire belt is clean, then rise with a separate sanitizer-soaked grill cloth to remove residue and soil. Performing this twice a week should lessen frequency of full belt recovery needs.

Monthly (as needed)

To begin the belt recovery, put on heat resistant gloves. Open drawer to access silicone belt. Spray the HAGTC onto a clean, sanitizer-soaked grill cloth and then evenly apply the cleaner to the hot silicone belt using the cloth. Do not spray the cleaner directly onto the belt. Once evenly coated, close the drawer and allow the belt to heat for 8 minutes. After this time, the cleaner is to be removed from the entire belt using another clean, sanitizer-soaked grill cloth until all cleaner residue is removed.

Monthly Deep Clean


1. Open drawer and coat silicone belt evenly.
2. Close drawer after application of cleaner and allow the belt to heat for 8 minutes.
3. Wipe off belt with clean sanitizer-soaked grill cloth.



Silicone Belt Install


1

Loosen belt tension by turning (8 to 10 full turns) screws located at the rear of the conveyor counterclockwise




2

Identify silicone belt ends. One end of the belt has a big flap and the other end does not have it




3

Starting on the front end of the conveyor (where gear motor is), place silicone belt clips without flap over master link (where slats were removed)




4

Snap clips to master link. Repeat this step until all clips from end of silicone belt have been snapped to master link.




5

Once all clips from end of silicone belt have been snapped in position, push belt forward using both hands until all the SS belt has been covered with the silicone belt.



6

Locate silicone belt clips from other end of belt (with flap) and bring over master link to snap into place (in master link). Repeat this step until all clips from end of silicone belt have been snapped to master link.



Silicone Belt Install (Continued)

7


Center silicone belt after it has been installed.



Bun Deflector Bar Install

1

Identify top and bottom part of deflector bar. Bottom of deflector bar has flange. Top of deflector bar has no flange.




Flange

No flange

2

Using channel locks, grab tension bracket and frame on the right side. Squeeze channel locks to open a gap between frame bracket and tensioner screw head. Repeat this step for left side.



Tensioner bracket

Frame bracket




Frame bracket

Tensioner screw head


3

When gap has been opened, slide one side of deflector bar between frame bracket and tensioner screw head on the right side. Repeat this step for the left side



Top of deflector bar (no flange)

Slide right side of deflector between frame bracket and tensioner screw head



Slide left side of deflector between frame bracket and tensioner screw head

Bottom of deflector bar (w/ flange)

4

After installing deflector bracket, tighten tensioner screw. Hold bracket down while tightening screw to prevent bracket from sliding out. Do this on right and left side.



Hold bracket down while tightening screws

Bun Deflector Bar Install (Continued)

5

After tightening screws, measure distance between tensioner bracket and frame bracket. Distance must be between 3/4" to 7/8" but the same on both sides



Distance between tensioner and bracket frame

Silicone Wrap Removal

1

Use scissors to cut and remove silicone wrap from unit



2

Push down both sides of bottom of clip



3

Repeat procedure from previous step for remaining clips



4

Pull each section of the silicone wrap out of unit. Then refer to installation instructions on page 11



Release Sheet Replacement


1

Remove Teflon release sheets retaining clips located over landing zone by lifting up on them. Be careful not to lose the retaining clips.



4

Re-clip heel-side release sheet first being sure to shift the sheet toward the upper step corner on the platen as shown.



2

Remove Teflon release sheets by first removing the in-feed rack and then by lifting up gently on the front retaining brackets located over the in-feed. Be careful not to lose the retaining brackets.



5

Reconnect retaining clips by holding the release sheet tight over the mounting rods, ensuring that they are straight. Press clips over rods until there is solid engagement.




3

Re-feed new release sheets back through the toaster, from the in-feed to out-feed side and reconnect the brackets.



6

Visually inspect that the sheets are taught and ripple free over the heater platen afterwards by peering down the heating chamber. Disconnect clips and reset if not.



Club Belt Replacement

Depending on toaster use, the club belts should be replaced approximately every 6 months. Belts should be replaced if worn or torn.

Torn belt should be replaced



- 1** Turn Toaster OFF and Unplug Toaster.



- 2** Put on a pair of high temperature gloves.


- 3** Remove right side cover from unit.



- 4** Pivot latch arm counterclockwise, and remove belt tension by pivoting tension arms towards the left..



- 5** Remove old belts.



- 6** Install new belts.



- 7** Be sure the bead on belt rides in groove in belt rollers.



Club Belt Replacement

8

Pivot tension arms down and engage latch arm.




9


Replace right side cover on unit.



Display Menu Options



Display Menu Options (Continued...)




Management Programming

1

To Enter Programming screens
Press and hold the MENU
button for 6 seconds. The
PROGRAMMING VERSION
screen will appear in the LCD
display.

From the PROGRAMMING
VERSION screen, you may:

Press RIGHT scroll
button to advance to the
next menu item




3

To Adjust PLATEN
TEMPERATURE from the
SELECT LANGUAGE Screen,
press the RIGHT scroll button.
Press the OK button to enter the
programming screen.

- A. From the PLATEN
TEMPERATURE screen that
appears adjust the tem-
perature using the RIGHT
and LEFT scroll buttons.

Accept the new Temperature by
pressing OK.

NOTE : To cancel without
accepting the new setting,
press the MENU logo button to
return to the previous screen




2

To Change the LANGUAGE
from the PROGRAMMING
VERSION

Screen, PRESS the left scroll
button.

From the SELECT
LANGUAGE Screen,
Press OK button

- A. From the
LANGUAGE screen
that appears, use
the RIGHT and
LEFT scroll buttons.
TO select different
Language
B. Accept the new
language by pressing
OK button to return to
the SELECT
LANGUAGE screen




4

To adjust SELECT F/C
From The PLATEN
TEMPERATURE screen,
press the RIGHT scroll
button.

From the SELECT F/C screen
that appears, press the OK
button.

- A. From the SET F/C
Screen that appears,
Use the LEFT and
RIGHT scroll buttons to
Select TEMP = F
(Fahrenheit) or
C (Celsius)
B. Accept the new scale
By pressing the OK
Button to return to
The SELECT F/C
screen



Management Programming (Continued)

5

To adjust set TOAST TIME from the SELECT F/C screen, press the RIGHT scroll button

From the SELECT TOAST TIME Screen, Press OK button

- A. From the SELECT TOAST TIME that appears, Adjust the set point Time Using the RIGHT and LEFT Scroll buttons. Accept The new toast time by Pressing OK.

NOTE : To cancel with\out accepting the new setting, press the MENU logo button to return to the previous screen



7

To enter LON SERVICE CALL from CLUB TOAST TIME screen, press the RIGHT scroll button.

From the LON SERVICE CALL Screen, Press OK button

From the LON SERVICE CALL screen that appears, the following options are available

YES = LEFT scroll button
 NO = RIGHT scroll button
 OK = Cancel / Go Back



8

To enter MFY STORE from LON SERVICE CALL screen, press the RIGHT scroll button.

From the MFY STORE Screen, Press OK button

From the MFY STORE screen that appears, the following options are available

YES = LEFT scroll button
 NO = RIGHT scroll button
 OK = Cancel / Go Back



6

To adjust CLUB TOAST TIME from the SELECT TOAST TIME screen, press the RIGHT scroll button

From the SELECT CLUB TOAST TIME Screen, Press OK button

- A. From the SELECT CLUB TOAST TIME that appears, Adjust the set point Time Using the RIGHT and LEFT Scroll buttons. Accept The new toast time by Pressing OK.

NOTE : To cancel with\out accepting the new setting, press the MENU logo button to return to the previous screen




Management Programming (Continued)

9

To view Service Codes, From the MFY Store screen, press the RIGHT scroll button once.

From the Service Codes screen,

- A. Select OK to check the service codes
- B. Refer to Service codes page to understand the operation of the unit.




10

Exit Programming

Press the MENU button from any screen to exit programming mode.




Exploded View and Parts List



Item #	Part #	Description	Qty
0	72-478	POWERCORD	1
1	66-045S	STRAIN RELIEF	1
2	78-223S	SWITCH, ROCKER, DPST, IP65, 16A	1
3	353-394S	THERMOSTAT, SNAP DISC CONTROL, 120	1
NOT SHOWN	527-127S	SERVICE KIT, CUTOFF SWITCH314	1
NOT SHOWN	353-206S	TRAY, OUTFEED ASSY	1
NOT SHOWN	353-1415S	CONVEYOR BASE ASSY	1

Exploded View and Parts List (Continued)




Item #	Part #	Description	Qty
4	353-054S	RELEASE SHEET BAR	2
5	353-053S	RELEASE SHEET CLIP	2

Horizontal Core Bun Toaster

CBT-SB-NA-1PS

Exploded View and Parts List (Continued)




Item #	Part #	Description	Qty
6	353-1415S	CONVEYOR, MAIN	1
7	353-442S	SKID BAR, CONVEYOR	4
31	353-1158S	CONVEYOR, BELT	1
32	353-1410S	DIVERTER, CONVEYOR	1
33	353-1412S	SILICONE WRAP	1
NOT SHOWN	353-1414S	MASTER LINK	1

Horizontal Core Bun Toaster


CBT-SB-NA-1PS

Exploded View and Parts List (Continued)



Item #	Part #	Description	Qty
8	353-1180S	MCD KIT, BEARING ASSEMBLY	2
9	353-241S	76-MCD KIT CBT MAIN CONVEYOR MOTOR	1
10	353-1179	MCD KIT CBT MAIN CNVR DRV BELT NEW REV	1
11	353-343S	MCD KIT, PLY, 3mmPITCH(HTD),44GROOVE,AL	2
12	353-1141S	MCD KIT,SHAFT, TENSIONING, CONVEYOR, CBT	1
13	353-205S	MCD KIT, CONVEYOR, SPROCKET SHAFT ASSY, CBT	1

Exploded View and Parts List (Continued)




Item #	Part #	Description	Qty
14	77-093S	MCD KIT, TERMINAL BLOCK 12POS 2ROW INSULATED	1
15	526-281S	MCD KIT, TSTAT, HI-LIMIT BULB & CAP, 700F	3
16	65-064S	MCD KIT, RELAY,SS,50A,280VAC,90-280VAC	2
17	85-147S	MCD KIT MEANWELL POWER SUPPLY, TOASTERS	1
18	353-262CS	MCD KIT, PCB, MAIN CONTROLLER	1
19	65-058S	MCD KIT, RELAY, SS,50A,280VAC,3-32VDC	3

Horizontal Core Bun Toaster
CBT-SB-NA-1PS




Exploded View and Parts List (Continued)



Item #	Part #	Description	Qty
20	353-208S	MCD KIT, CBT HEATER PLATEN, 3600W/240V, CNVYR	1

Exploded View and Parts List (Continued)




Item #	Part #	Description	Qty
21	37814S	MCD KIT MOTOR FAN 230V CBT/IRT/SK	1
22	353-1315S	MCD KIT, *Shared* LCD GRAPHIC DISPLAY W/NYLON NUTS, CBT/IRT	1
23	353-1306S	MCD KIT, IRT/CBT FAN FILTER KIT	1

Horizontal Core Bun Toaster

CBT-SB-NA-1PS

Exploded View and Parts List (Continued)



Item #	Part #	Description	Qty
24	353-242S	MCD KIT CBT CLUB MOTOR	1
25	353-343S	MCD KIT, PULLEY, 3MM PITCH(HTD), .44 GROOVE, AL	2
26	353-1074S	353-5MCD KIT CBT BELT, 3MM HTD, 80 TEETH	1
27	527-819S	MCD GEAR, SPR,56 TTH,24.P,2.333P.D..25	2
28	353-1018S	MCD KIT CLUB ASSY, BOTTOM CBT	1
29	353-1017S	MCD KIT TOP CLUB ASSY, CBT	1
30	353-1251S	MCD Kit, BRACKET,BEARING,CLUB ASSEM, CBT	4

Horizontal Core Bun Toaster

CBT-SB-NA-1PS



Troubleshooting Guide

BURN/ELECTRICAL SHOCK HAZARD! Platen is HOT and can cause severe burns or severe shock.
Keep hands and objects out of the toaster unit! Failure to exercise caution may result in serious injury!
Turn the unit off, let it cool down completely before touching or working on internal apparatus.

Master Display Messages		
PROBLEM	PROBABLE CAUSE	SOLUTION
Unit will not heat up	No power to unit.	Ensure power cord is connected to proper receptacle.
	Inoperable power cord	Call for Service (800) 722-7853
	Loose connection on power switch	Call for Service (800) 722-7853
	Inoperable power switch	Call for Service (800) 722-7853
	High limit switch tripped	Call for Service (800) 722-7853
	Inoperable Temperature Probe	Call for Service (800) 722-7853
	Inoperable Platen	Call for Service (800) 722-7853
Unit heats up, but the conveyor does not run	Loose motor switch connection.	Call for Service (800) 722-7853
	Inoperable motor.	Call for Service (800) 722-7853
	Inoperable motor switch.	Call for Service (800) 722-7853
	Stripped drive gear	Call for Service (800) 722-7853
	Loose chain sprockets	Call for Service (800) 722-7853
Unit under-and over-heats, but does not respond to programming.	Check temperature settings	Adjust temperature set point setting. See management programming.
	Inoperable temperature probe	Call for Service (800) 722-7853
Buns under-or over-done.	Check platen adjustment. See operation manual	Move platen adjustment to the correct product part setting.
	Check conveyor temperature. From READY screen, press the INFORMATION button to display the actual	Adjust temperature set point setting. See management programming.
	Improper toast time.	Adjust toast time as needed.